

# The Wanderer™

## Cordless Key Telephone



## User Guide



# ***The Wanderer***<sup>™</sup>

*Cordless Key Telephone Unit*

## **User Guide**

Issue 1 - August, 2002

P/N: 9018-10

<b>Issue</b>	<b>Release Date</b>	<b>Changes</b>
1	08-02	Initial Release

**LIFE SUPPORT APPLICATIONS POLICY**

**VODAVI Technology, Inc.** products are not authorized for and should not be used within Life Support applications. Life Support systems are equipment intended to support or sustain life and whose failure to perform when properly used in accordance with instructions provided can be reasonably expected to result in significant personal injury or death.

**VODAVI Technology, Inc.** warranty is limited to replacement of defective components and does not cover injury to persons or property or other consequential damages.

**Copyright © 2002 VODAVI Communications Systems, Inc.**

**All Rights Reserved**

This material is copyrighted by VODAVI Communications Systems. Any unauthorized reproductions, use or disclosure of this material, or any part thereof, is strictly prohibited and is a violation of the Copyright Laws of the United States (17 U.S.C. Section 101 et. seq.).

VODAVI reserves the right to make changes in specifications at any time and without notice. The information furnished by VODAVI in this material is believed to be accurate and reliable, but is not warranted to be true in all cases.

*The Wanderer™* is a registered trademark of  
VODAVI Communications Systems, Inc.

mlj/2002

---

---

# Contents

<b>About the Wanderer</b> .....	<b>1</b>
Product Overview .....	2
<b>Initial Setup</b> .....	<b>3</b>
Installing Your Cordless Phone .....	3
Verify Parts Received .....	3
Connect Cables .....	3
Supply Power .....	3
Activating Your New Wanderer .....	4
Initialize Handset to Charging Base .....	4
Register Station Number to Handset .....	4
Assign CKTU Mode .....	4
<b>Using Your New Wanderer</b> .....	<b>5</b>
When to Recharge Handset .....	5
Talk Time .....	5
Standby Time .....	5
Low Battery Indication .....	5
Answering Calls .....	5
Placing Calls .....	6
Intercom Calls .....	6
Outside Calls .....	6
Button Features .....	7
CONFERENCE Button .....	7
FLASH Button .....	8
FLEXIBLE Button .....	8
HOLD Button .....	9
MUTE Button .....	10
ON/OFF Button .....	10
SPEED Button .....	11
TRANSFER Button .....	12
VOLUME Buttons .....	12
Other Features and Functions .....	13
Pager Call .....	13
Redialing .....	13
Ringing Signal .....	13
LED Indicators .....	14
LCD Displays .....	14
<b>Frequently Asked Questions</b> .....	<b>19</b>

---

---



---

---

## *About the Wanderer*

The *Wanderer*<sup>™</sup> is a light-weight, 2.4 GHz, digital cordless handset for use with your digital key telephone.

Take the *Wanderer* to a nearby office, a meeting, a conference room, or to check inventory ... you are still available through your extension!



### *Cordless Capabilities ... and ... Digital Quality*

For **maximum clarity and range**, the *Wanderer's* Digital Spread Spectrum Technology spreads the signal over one of 40 independent frequency ranges.

A **pre-assigned digital code** is shared by the charging base and handset to prevent other radiated frequencies from interfering with system sound quality.

**Signal strength** is constantly monitored and the system automatically selects one of three power levels to gain maximum range and optimal battery life.

A **digital coding security system** is used to prevent unauthorized use of your telephone by other nearby cordless telephone users.

*About the Wanderer**Product Overview*

The **Handset** is a lightweight design with an easy-to-read display and comfortable soft keypad buttons.

*Handset features also include:*

10 Interactive Feature Buttons:

CONF	ON/OFF
FLASH	SPEED
FLEX	TRANS
HOLD	VOL DOWN
MUTE	VOL UP

12-button Dial Pad

2-line x 12-character LCD Display

Antenna

Power Switch (*located on bottom of handset*)

Headset Jack (*located on side of handset*)

Hearing-aid Compatible Receiver




The **Charger Base** is a compact unit that can be placed on any flat surface.

*Base features also include:*

Radio frequency and voice path circuitry

Pager Call button to locate handset

LED indicators for Power, Talk, Call, and Charger



---

## Initial Setup

### *Installing Your Cordless Phone*

#### Verify Parts Received

Remove all contents from the shipping box, and check the items received with the following list:


- |                         |                   |
|-------------------------|-------------------|
| ✓ Desktop charging base | ✓ Ni-MH battery   |
| ✓ Handset               | ✓ Power adaptor * |
| ✓ Modular cable *       | ✓ User Guide      |



\* To ensure proper connections ... *ONLY* use the cable and adaptor provided with your new Wanderer.

#### Connect Cables

1. Unplug the cable from your existing wired telephone. Plug this cable into the charger base jack labeled KSU.
2. Plug the modular cable supplied with the *Wanderer* into the charging base jack labeled KTU. Plug the other end of this cable into your existing wired telephone.



#### Supply Power

1. Plug the power adaptor into a wall outlet. Plug the other end into the charging base where it is labeled *DC IN 12V*.
2. Turn the switch on the bottom of the *Wanderer* to the ON position and place the handset in the charging base.
3. Charge your new *Wanderer* for 12-14 hours.

## *Initial Setup*

### *Activating Your New Wanderer*

#### **Initialize Handset to Charging Base**

*To associate your Wanderer with your Station Number:*

Simultaneously press and hold the [PAGER CALL] button on the charging base and the [FLASH] button on the handset for ten seconds ... or until "REGISTER" appears on the display.

*(The unit will beep once to indicate registration is complete.)*

#### **Register Station Number to Handset**

Although station number registration is automatic ... use this procedure to prevent a "previously saved number" from appearing on the *Wanderer* display (e.g., new ext. number).

*From your Wanderer, perform the following steps:*

1. Press [HOLD].
2. From the dial pad, enter a station or intercom number.  
(Up to four digits may be entered, however, your intercom or extension number is recommended.)
3. Press [HOLD].

#### **Assign CKTU Mode**

*From your telephone, activate the CKTU mode as described:*

##### *Display Telephone*

1. Dial [6] + [4] + [8] on the dial pad.
2. Press [\*] repeatedly until **CKTU** appears on the display.
3. Press [HOLD] to save.

##### *Non-display Telephone*

Contact your System Administrator.

---

## Using Your New Wanderer

Review this section for step-by-step operating instructions.

### *When to Recharge Handset*

The *Wanderer* will send an audible alert to indicate *recharging*.

#### Talk Time

You can talk for approximately **4 hours** on your *Wanderer* before recharging is necessary.

#### Standby Time

Your *Wanderer* may be idle and out of its base for approximately **40 hours** before recharge is necessary

#### Low Battery Indication

The LCD on the *Wanderer* indicates a low battery condition when the battery charge falls below 25%.



LOW BATTERY

*Wanderer* handset emits a tone at 30-second intervals until it is returned to the charging base. When LCD indicates a low battery condition, it should be charged for **at least 8 hours**.

### *Answering Calls*

When your *Wanderer* rings, the LCD indicates **Ringin**g.

1. If handset is in charging base and ringing, simply remove it to answer the call. You do not need to press [ON/OFF].  
-or-  
If carrying handset, press [ON/OFF] to answer the call.
2. Press [ON/OFF] to end the call.



*The wired telephone may ring 1-2 times before the Wanderer rings. This is normal operation.*

---

*Using Your New Wanderer*

---

## *Placing Calls*

When you place a call, the *Wanderer* LCD indicates **Talk**.

### **Intercom Calls**

1. Remove the *Wanderer* from the charger base and press [ON/OFF] to access a dial tone.
2. Dial the intercom number.
3. Press [ON/OFF] to end call.

### **Outside Calls**

1. Remove the *Wanderer* from the charger base and press [ON/OFF] to access a dial tone.
2. Dial [9] to access an outside line dial tone.
3. Then dial the desired phone number.
4. Press [ON/OFF] to end call.

### *CONDITIONS*

- » If multiple lines are ringing, the “oldest” is answered first.
- » Outside line calls have priority over intercom calls.
- » If [ON/OFF] is pressed during a call, that call is terminated.
- » The *Wanderer* does NOT audibly ring if it is in the charging base, or if it is out of the charging base and turned OFF.
- » Both the telephone and the *Wanderer* audibly ring if the handset is not in the charging base and is turned ON.
- » Only 1 call may be put on hold at a time on the *Wanderer*.
- » Calls may not be placed from your cordless handset while the telephone is active. “Base Busy” appears on the LCD.
- » Depending on environmental conditions, you may notice an increase or decrease in the call range when using the *Wanderer*. *This is the nature of the radio frequency signal.*

## *Button Features*

This section describes how to use each of the *Wanderer's* ten feature buttons.

### **CONFERENCE Button**

A conference call supporting up to eight parties can be originated from the *Wanderer*.

*To initiate a conference call:*

1. While on a call, press [CONF] to place the party on hold. Listen for a dial tone.
2. To add outside parties to a conference call, dial [9] + telephone number.  
-or-  
To add internal parties to a conference call, dial the extension number.
3. When the party answers, press [CONF] to place the party on hold.
4. To add additional parties to the conference call, repeat steps 1 through 3 until all appropriate parties are on hold.
5. Press [CONF] + [CONF] to connect all parties.
6. Press [ON/OFF] to end the conference call.

#### *CONDITIONS*

- » The number of outside parties is limited by the number of line appearances on the telephone.
- » Individual parties may be dropped from the conference call through the telephone only. Individual parties may not be dropped from your *Wanderer*.

*Using Your New Wanderer***FLASH Button**

The FLASH button can be used to:

Terminate a call, and place a new call.

Activate certain features provided by your phone company.

*CONDITIONS*

- » Flash feature may be stored as part of Speed Dial number.
- » Pressing the FLASH button will have the following results:
 

while connected to intercom ...	reinitiates the intercom dial tone.
while on an outside call ...	terminates call & restores dial tone.
during an intercom call or page announcement ...	will not terminate the intercom call or page announcement.

**FLEXIBLE Button**

The Flexible Button (FLEX) on the *Wanderer* may be assigned to function as one of the 24 flexible buttons on your telephone.



*The desired feature must be programmed as a button on the telephone prior to activating the FLEX button on the Wanderer.*

*To assign the FLEX button on the Wanderer:*

1. Press [ON/OFF] on the *Wanderer*.
2. Press [SPEED] + [SPEED] on the *Wanderer*.
3. Press [FLEX] on the *Wanderer*.
4. Press the desired flexible button on the keyset telephone.  
Listen for confirmation tone on the *Wanderer*.
5. Press [ON/OFF] on the *Wanderer*.

*CONDITIONS*

- » The default assignment is NONE.
- » Not all features can be assigned to the FLEX button (Answering Machine Emulation, Call Screening, etc.).

## **HOLD Button**

This feature allows you to place a call on hold.

*To place or retrieve a call on hold:*

1. While on an outside line call, press [HOLD] to place the call on hold.
2. Press [HOLD] again to retrieve the call.

*To place an outside call while on hold:*

1. Press [HOLD].
2. Press [ON/OFF] to enter idle mode.
3. Press [ON/OFF] again, listen for dial tone. Place the outside call.
4. Press [ON/OFF] to end the call and enter idle mode.
5. Press [HOLD] to retrieve the call on hold.

*To switch calls from the Wanderer to the telephone:*

1. Press [HOLD] to place the call on hold.
2. Press [ON/OFF].
3. Pick up the call by pressing the flashing, outside line, loop or intercom button on the telephone.

*To switch calls from the telephone to the Wanderer:*

1. Place the call on hold at the telephone.  
Make sure [ON/OFF] button is not lighted and the handset is in cradle.
2. Press [ON/OFF] on the *Wanderer*.
3. Press [HOLD] to pick up the call on the *Wanderer*.

*To process multiple calls from your Wanderer:*

1. Press [HOLD] to place your call on hold. An intercom dial tone is heard.
2. Dial an intercom number or a trunk group access number to be connected to a second call.  
If [HOLD] is pressed while on the second call, it is ignored.

---

*Using Your New Wanderer*

---

*CONDITIONS*

- » Only one call at a time may be placed on hold.
- » If multiple calls are on hold at the telephone, the *Wanderer* retrieves the last call put on hold.
- » Intercom calls may be placed on hold or retrieved, provided there are intercom flex buttons assigned on the telephone.

**MUTE Button**

The Mute button may be pressed during a conversation to disable the *Wanderer* microphone. This feature is useful in noisy environments, or if a private side-conversation is desired.

*While on an intercom or outside line call:*

1. Press [MUTE] to disable the microphone.
2. Press [MUTE] again to enable the microphone.

The LCD will indicate **Mute** while function is active.

**ON/OFF Button**

The ON/OFF button on your *Wanderer* is used to answer calls and place calls. The handset must be turned ON and removed from the charger base.

To activate handset, press [ON/OFF]. LCD will display **Search**.

Once the base is located, the display will indicate **Talk**.

If the *Wanderer* is unable to find the base ... three short beeps will sound.

## **SPEED Button**

You may assign Speed Dial numbers on your *Wanderer* to provide speedy access to frequently-used telephone numbers.

*To program a speed dial number:*

1. Press [ON/OFF].
2. Press [SPEED] + [SPEED], then enter the Bin Number.
3. Dial the telephone number to be stored.
4. Press [SPEED] then [ON/OFF].

*To dial a speed dial number:*

1. Press [ON/OFF].
2. Press [SPEED], then enter the Bin Number.

*To clear a speed dial number:*

1. Press [ON/OFF].
2. Press [SPEED] + [SPEED], then enter the Bin Number.
3. Press [SPEED].
4. Press [ON/OFF].

### *CONDITIONS*

- » A Speed Dial number bin can contain 24 digits including:

Pause	Press [HOLD]
Pulse to DTMF Switchover	Press [TRANS]
Flash Commands	Press [FLASH]
Display Security (conceals dialed numbers on LCD)	Press [TRANS] as 1st digit in bin

- » If all outside lines are busy when you dial a Speed Dial Number, a busy tone is heard.
- » Speed Dial numbers are protected by Battery B/U Memory.
- » Speed Dial bins access outside lines only and cannot be programmed to access internal numbers.

*Using Your New Wanderer***TRANSFER Button**

External and internal calls may be transferred to idle or busy stations by performing the following steps:

## SCREENED TRANSFER

*While on a call:*

1. Press [TRANS] + station number.
2. When the call is answered, announce the transfer.
3. Press [ON/OFF] to complete the transfer.

## UNSCREENED TRANSFER

*While on a call:*

1. Press [TRANS] + the station number.
2. Press [ON/OFF] to complete the transfer.

**VOLUME Buttons**

These buttons may be used to modify the volume for both voice and ring sound levels.

## VOICE RECEIVE VOLUME

*To adjust the voice receive volume while on an intercom or outside line call:*

1. Press [VOL UP] to increase volume.
2. Press [VOL DOWN] to decrease volume.

## RING VOLUME

*To adjust the ring volume while in idle mode:*

1. Press [VOL UP] to increase volume.
2. Press [VOL DOWN] to decrease volume.

## CONDITIONS

- » Three Voice Receive Volume levels are available.
- » Two Ring Volume levels are available - High and Low.

## *Other Features and Functions*

### **Pager Call**

The Pager Call button is located on the charger base and is used to locate the *Wanderer* handset.

1. Press [PAGER CALL] on the charger base. The base sends a stutter tone burst to the handset for 30 seconds, and the LCD on the handset indicates **Paging Call**. Repeat as necessary until your *Wanderer* is located.
2. Press [ON/OFF] on the handset to stop the ringing.

#### *CONDITIONS*

- » When Pager Call button is activated, the Call LED pulses.

### **Redialing**

*To redial an outside call:*

1. Press [ON/OFF].
2. Press [SPEED] + [#].

*For added security, only the [#] sign appears on the LCD display.*

### **Ringling Signal**

The audible ring signal on the *Wanderer* can identify the type of incoming call as internal or external.

Internal Ring Signal ... a *single* ring is repeated.

External Ring Signal ... a *double* ring is repeated.

#### *CONDITIONS*

- » The telephone associated with the *Wanderer* may ring once or twice before the *Wanderer* rings.
- » A screened transfer call rings as an internal call until the supervising party hangs up, then it changes to an external signal.

*Using Your New Wanderer*

### LED Indicators

The LED indicators on the charging base function as follows:

- Power ... lights when the base is properly plugged in
- Talk ... lights during an active call
- Call ... pulses when the Pager Call button is activated
- Charger ... lights when handset is resting properly in base

### LCD Displays

The following examples show each calling mode and call status that could appear on your *Wanderer* display screen.

First group of LCDs -- displays you might see "while the *Wanderer* and the Keypad are both idle".

Second group of LCDs -- displays you might see on the *Wanderer* when it is idle, but while "the associated keypad" is being used.

Active Call LCD -- You will see this display whenever you are on a call.

```
T A L K
X X X X X X
```

#### ***Wanderer Displays ... while Wanderer & Keypad are idle***

ACD/UCD LOGON  
(Primary & Secondary)

```
  S T A   X X X X
P X X X X   S X X X X
```

CALL BACK BY A STATION

```
  C A L L   B A C K
F R O M   X X X X
```

ACD/UCD CALLS IN QUEUE DISPLAY

```
X X X X   C I Q : C C
A G E N T ( S ) : X X
```

CALL FOR A STA (Call Coverage)

```
  C A L L   F O R
S T A   X X X X
```

ACD/UCD UNAVAILABLE STATUS

```
U N A V A I L A B L E
U C D   X X X X
```

CALL FROM A STA - direct  
CALL FROM A STA - via another Sta  
(Sta # or Name displays)

```
  C A L L   F R O M
S T A   X X X X
```

CALL FWD (ALL) TO ACD/UCD GRP

```
FORWARDED TO
UCD XXXX
```

CALL FWD (ALL) TO HUNT GRP

```
FORWARDED TO
HUNT XXXX
```

CALL FWD (ALL) TO A STA - (name or #)

```
FORWARDED TO
nnnnnnn
```

CALL FWD (ALL) TO VOICE MAIL

```
FORWARDED TO
VOICE MAIL
```

CALL FWD (BSY/NA) TO ACD/UCD GRP

```
BSY / NA FWD
UCD XXXX
```

CALL FWD (BSY/NA) TO HUNT GRP

```
BSY / NA FWD
HUNT XXXX
```

CALL FWD (BSY/NA) TO A STA

```
BSY / NA FWD
STA XXXX
```

CALL FWD (BSY/NA) TO VOICE MAIL

```
BSY / NA FWD
VM XXXX
```

CALL FWD (BUSY) TO ACD/UCD GRP

```
BUSY FWD TO
UCD XXXX
```

CALL FWD (BUSY) TO HUNT GRP

```
BUSY FWD TO
HUNT XXXX
```

CALL FWD (BUSY) TO A STA

```
BUSY FWD TO
STA XXXX
```

CALL FWD (BUSY) TO VOICE MAIL

```
BUSY FWD TO
VM XXXX
```

CALL FWD (NO ANS) TO ACD/UCD GRP

```
N / A FWD TO
UCD XXXX
```

CALL FWD (NO ANS) TO HUNT GRP

```
N / A FWD TO
HUNT XXXX
```

CALL FWD (NO ANS) TO A STA

```
N / A FWD TO
STA XXXX
```

CALL FWD (NO ANS) TO VOICE MAIL

```
N / A FWD TO
VM XXXX
```

CALL FWD TO REMOTE DEVICE #

```
FWD TO RDN
XXXX
```

CALL TRANSFERRED FROM  
(Sta # or 7-digit name)

```
XFR FROM
STA XXXX
```

*Using Your New Wanderer***CO LINE NUMBER IS RECALLING**

```

LINE XXX
RECALLING

```

**DO NOT DISTURB - You are in DND**

```

STA IN DND

```

**IDLE DISPLAY - Sta # format**

```

STA XXXX

```

**IDLE DISPLAY - Sta # & Name format**

```

STA XXXX
nnnnnnn

```

**INCOMING CO LINE CALL  
(brief initial indication)**

```

RINGING

```

**INCOMING CO LINE CALL  
(Name or Number info, if available)**

```

NAME / NUMBER
LINE RINGING

```

**LINE HOLDING - You are holding a CO  
Line XXX (Excl Hold must be priority)**

```

LINE HOLDING
LINE XXX

```

**MESSAGES WAITING**

```

MSG : XXXX
XXXX XXXX

```

**NAME/NUMBER FORWARD RING**

```

NAME / NUMBER
FORWARD RING

```

**OFF-HOOK VOICE OVER  
ANNOUNCEMENT FROM A STA**

```

ANNOUNCE
FROM XXXX

```

**PAGE FROM A STATION**

```

PAGE FROM
STA XXXX

```

**QUEUE CALLBACK**

```

QUEUE
CALLBACK

```

**QUEUE FOR A LINE NUMBER**

```

QUEUE FOR
LINE XXX

```

**STA & HUNT GRP ASSOCIATION**

```

STA XXXX
HUNT XXXX

```

**TRANSFER RECALL**

```

RECALL FROM
LINE XXX

```

**VOICE MAIL MSGS IN QUEUE  
(analog - # of NEW VM msgs)**

```

NEW VM MSGS
XXX

```

**VOICE MAIL MSGS IN QUEUE  
(digital - # of ALL VM msgs)**

```

VM MESSAGES
XXX - XXX - XXX

```

**Wanderer Displays ... while using Keyset**

ACD/UCD CIQ - Keyset on CO Line Call  
 ACD/UCD CIQ - Keyset on Internal Call  
 (with incoming calls)

```
XXXX CIQ: CC
AL: aa OC: ooo
```

ACD/UCD STATUS - Code 567 dialed at  
 keyset to display group status

```
UCD XXXX
CALLS IN QUE
```

CALL FWD - OFF-NET

```
FWD OFF NET
LINE XXX
```

CALL TO STA (CO) - call in progress

```
STA XXXX
LINE XXX
```

CALL TO STA (CO) - that you picked up  
 CALL TO STA (INT) - prior to pickup  
 CALL TO STA (INT) - that you picked up  
 CALL TO STA - picked up by other Sta  
 CALL TO STA - via ACD/UCD Group  
 CALL TO STA - via Hunt Group

```
CALL TO
STA XXXX
```

CALL TO VM VIA VOICE MAILBOX #

```
CALL TO VM
VIA XXXX
```

CAMP ON BY A STATION

```
CAMP - ON BY
STA XXXX
```

CONFERENCE CALL

```
CONFERENCE
```

DO NOT DISTURB - Called Sta is in DND  
 (Sta # or 7-digit name)

```
DND STA XXXX
```

FORWARDED TO A STA - Your call to  
 another destination (by Sta #)

```
FORWARDED TO
STA XXXX
```

IN-PROGRESS CALL INDICATION

```
LINE XXX
```

LEAST COST ROUTING

```
LCR
```

LEAST COST ROUTING QUE CALLBACK

```
LCR QUEUE
CALLBACK
```

MESSAGES - 1st 12 digits (code 633)

```
ABCDEFGHIJKL
```

---

*Using Your New Wanderer*
*OFF-HOOK VOICE OVER ANNOUNCE  
TO ANOTHER STA*

```
ANNOUNCE TO
STA XXXX
```

*OUT OF SERVICE (called Sta is OOS)*

```
STA XXXX
OUT OF SVC
```

*PAGE - ALL CALL (from Wanderer)*

```
ALL CALL
PAGE
```

*PAGE - External Zones (All)*

```
EXTERNAL ALL
CALL PAGE
```

*PAGE - External Zone number*

```
EXTERNAL
PAGE ZONE XX
```

*PAGE - Internal Zones (All)*

```
INTERNAL ALL
CALL PAGE
```

*PAGE - Internal Zone number*

```
INTERNAL
PAGE ZONE XX
```

*QUEUE FOR A GROUP NUMBER*

```
QUEUE FOR
GROUP XX
```

*RECORDING MODE*

```
RECORDING
```

*RECORDING SETUP*

```
RECORDING
SETUP
```

*RECORDING UNAVAILABLE*

```
RECORDING
UNAVAILABLE
```

*SCREENING MODE*

```
SCREENING
```

*SCREENING RING MODE*

```
SCREENING
RING
```

*STATION MONITORING*

```
MONITORING
STA XXXX
```

*VOICE MAIL - Call to Voice Mail*

```
CALL TO
VOICE MAIL
```

*VOICE MAIL - Forward to VM via Sta #*

```
FWD TO VM
VIA STA XXXX
```

## Frequently Asked Questions

Answers to some common questions have been addressed in the following table:

Question	Answer
After I plug the adapter into a wall outlet and the charging base, why don't I have power, or the LED light up?	Verify the following: <ul style="list-style-type: none"> <li><input type="checkbox"/> Ensure the switch on the bottom of the handset is in the ON position.</li> <li><input type="checkbox"/> If you own a 900 MHz <i>Wanderer</i>, make sure its adapter was not used by mistake. It is not compatible with the 2.4 GHz model.</li> </ul>
Why doesn't the handset charge?	Check the contacts and battery pack: <ul style="list-style-type: none"> <li><input type="checkbox"/> Ensure that the contacts on both the charger base and the handset are in contact during charging. The contacts may need to be cleaned with an alcohol-moistened cloth.</li> <li><input type="checkbox"/> The Ni-MH battery pack may need to be totally discharged, before a full charge is possible.</li> </ul>
Why can't I make a call from my <i>Wanderer</i> ? When I press the ON/OFF button to make a call, the LCD indicates Searching, beeps 3 times and displays my Station Number.	The <i>Wanderer</i> cannot locate its charging base for one of the following reasons: <ul style="list-style-type: none"> <li><input type="checkbox"/> Out of range</li> <li><input type="checkbox"/> Charging base power unplugged</li> <li><input type="checkbox"/> Incoming call</li> </ul>
Why doesn't the <i>Wanderer</i> ring when it is out of the charging base?	There are several reasons why the <i>Wanderer</i> may have stopped ringing: <ul style="list-style-type: none"> <li><input type="checkbox"/> The handset may be out of range or turned OFF.</li> <li><input type="checkbox"/> Check H-T-P settings on the wired telephone for Hands-Free mode. The telephone must be in Tone Mode for <i>Wanderer</i> to ring.</li> <li><input type="checkbox"/> If "Distinctive Ringing" on the wired telephone is set to Type 36 (no ring), <i>Wanderer</i> LCD displays ringing, but no tone is heard.</li> </ul>

---

*Frequently Asked Questions*


---

<b>Question</b>	<b>Answer</b>
Why can't I initiate a conference call?	Contact your System Administrator to confirm "Conference" feature is enabled.
When I try to assign my display telephone to the CKTU mode, why doesn't the Wanderer display update with digital keyset information?	<p>Confirm software version.</p> <p>Version 1.11 or greater for XTS systems, or version 4.11 or higher for other Vodavi key systems, must be installed to enable CKTU mode and use the <i>Wanderer</i>.</p>
Why do I hear another call on the line or experience radio frequency interference (chattering or hum) while on a call?	<p>There is frequency interference for one of the following reasons:</p> <ul style="list-style-type: none"> <li><input type="checkbox"/> The handset rechargeable Ni-MH battery pack may need charging.</li> <li><input type="checkbox"/> Outside normal operating range. Move closer to the charging base.</li> <li><input type="checkbox"/> Within 20 feet of a working microwave.</li> </ul>
Why doesn't the Wanderer have dial tone or no longer rings?	<p>Verify each of the following conditions:</p> <ul style="list-style-type: none"> <li><input type="checkbox"/> Check that the telephone line connectors are fully pushed into the unit until they click.</li> <li><input type="checkbox"/> Check the Ni-MH battery pack connection inside the battery compartment of the handset.</li> <li><input type="checkbox"/> If there was a power failure or the charger base was unplugged, replace handset on charging base for 2-5 seconds. This will reset the system.</li> <li><input type="checkbox"/> Ensure that the handset and charger base are registered to each other. If not, the handset cannot connect to the phone line to dial out.</li> </ul> <p>(Refer to <i>"Initialize Handset to Charging Base"</i> on page 4.)</p>
Why do I sometimes receive an audible beeping tone at five-second intervals, sometimes followed by a call disconnect?	<p>One of the following could apply:</p> <ul style="list-style-type: none"> <li><input type="checkbox"/> Audible tone at 5-second intervals indicates an out-of-range status.</li> <li><input type="checkbox"/> Move the <i>Wanderer</i> back within range and the beeping will cease.</li> <li><input type="checkbox"/> A call could disconnect if the <i>Wanderer</i> is out-of-range for more than 15-20 seconds.</li> </ul>





WE'RE TALKING  
TECHNOLOGY  
[www.vodavi.com](http://www.vodavi.com)

**Part Number: 9018-10**